

Erledigt

OZMOSIS REQUEST THREAD / Ozmosis

Anfragen [1. Beitrag beachten!]

Beitrag von „Zhaman“ vom 26. Oktober 2016, 21:40

Zitat von al6042

You have to do a NVRAM-Reset after putting the defaults.plist in the directory /EFI/Oz on your hidden EFI-Partition.

This can be done by going in your BIOS and use the following key combination:

Alt+WinLogo+P+R

use the keys sequentially and hold them down.

The computer will do a reboot and load the complete Ozmosis environment, including the new defaults.plist.

I can not figure out where to find this hidden partition EFI? I simply do not have.