

## Erledigt Ozmosis for z77mxquoaos?

Beitrag von „MacGrummel“ vom 1. November 2016, 19:56

If You want to load any special kext or Defaults.plist from EFI You have to reset the P-Ram. Your P-List has to be put at EFI/EFI/Oz and has to be named as Defaults.plist..

