

# Lenovo Thinkpad T530

**Beitrag von „5T33Z0“ vom 19. Oktober 2020, 17:04**

[antukst](#) Download my EFI (since it's newer) put it on a FAT32 formatted USB Stick, stick it in the USB2 Port and boot from it using F12 and see what happens... deactivate discrete NVidia GPU in BIOS if it has one.