

# Lenovo 430s Catalina install, efi erstellen ?, anymacos-tinu

**Beitrag von „fredo“ vom 13. Juli 2021, 11:04**

Die nicht nötigen Treiber habe ich gerade entfernt, wie bekommen ich denn die HD4000 als Device da rein? kann ich da einfach die Werte von deinem L430 übernehmen?

Edit1: Ich habe jetzt einfach mal deinen Device Entry für die HD 4000 übernommen. Bleibt aber an der gleichen Stelle hängen. Was man ohne SSDT-CPU machen muss habe ich im Guide noch nicht gefunden.

Edit2: Glaube das ist die Lösung bei der Installation, wenn keine SSDT-CPU vorhanden ist:

"Initialing with OpenCore's setup in the Ivy Bridge section, we recommended users drop their CpuPm and Cpu0Ist to avoid any issues with AppleIntelCPUPowerManagement.kext. But dropping these tables have the adverse affect of breaking turbo boost in Windows. So to resolve this, we'll want to keep our OEM's table but we'll want to add a new table to supplement data only for macOS. So once we're done creating our CPU-PM table, we'll re-add our OEM's CPU SSDTs.!

Das habe ich in der config.plist schon genau so drin.

Hier nochmal mein EFI: