

Erledigt

WindowServer: Surface Test allowed after XX attempts

Beitrag von „Adnarel“ vom 7. Januar 2016, 14:21

Das lässt sich nicht einstellen, vermutlich weil der Sensor fehlt.

~~Vielleicht ganz einfach:-~~

ATX4P (PCIe Power Connector)

"When 2 or more graphic cards are installed, we recommend that you connect the SATA Power cable from the power supply to the ATX4P connector to ensure system stability."

Hab ja nur eine, aber vielleicht hilft es, wieder gebootet, schien weg.

Aber wie ich hier so schreibe plötzlich wieder 100 Einträge in ner Reihe.

Diesmal auch ein paar andere dazwischen gestreut:

```
14:18:02 WindowServer: Surface test allowed updates after 12 attempts
14:18:03 WindowServer: Surface testing disallowed updates for 18 sequential attempts...
14:18:03 WindowServer: Surface test allowed updates after 14 attempts
14:18:06 WindowServer: window 3a2 is already attached to window 3a0
14:18:06 WindowServer: window 3a2 is already attached to window 3a0
14:18:06 WindowServer: window 3a2 is already attached to window 3a0
14:18:07 WindowServer: Surface testing disallowed updates for 18 sequential attempts...
14:18:07 WindowServer: Surface test allowed updates after 16 attempts
14:18:08 WindowServer: Surface testing disallowed updates for 18 sequential attempts...
14:18:08 WindowServer: Surface test allowed updates after 16 attempts
14:18:08 WindowServer: _DIOGetWindowOrderingGroup: Operation on a window 8c32 requiring rights 0x0 by caller Systementstellungen
14:18:08 WindowServer: Surface testing disallowed updates for 18 sequential attempts
```