

**Erledigt**

## **MSI GE70 2PC Apache - DSDT/SSDT - Hilfe**

**Beitrag von „al6042“ vom 28. Juli 2016, 20:41**

I don't understand your answer...

I didn't what you put into your config.plist in Clover... but while we're at it... set layout-id to "Detect" so the entry within the DSDT works.

Also disable any DSDT-Fixes in Clover, since those are already in the patched DSDT...

You said you have the same laptop as JeromeM90...

I don't know that laptop, but I guess it has to have at least one audio jack, where you can either connect headphones or a stereo loudspeaker set...

So what are you talking about "lower" and "upper" or "rear" and "front" speakers?

What kind of speaker set are you using and how is this connected to the laptop?