

Erledigt

iStat Menus / HW-Monitor Anzeige der Lüfterdrehzahl

Beitrag von „sunraid“ vom 2. März 2019, 12:50

Die beiden o. g. Apps bieten schon eine ganze Menge Infos an. Hätte aber gerne noch die Lüfterdrehzahl (CPU-Lüfter) angezeigt. Wie bekomme ich das hin bzw. ist das überhaupt möglich?

Board ASUS Prime Z390-A

iStat aktuelle Vollversion

Systemangaben:

Date	Sa 2 März 2019 12:41:52 CET
OS Version	10.14.3
OS Build	18D109
Model Name	iMac
Model Identifier	iMac18,3
Processor	Intel(R) Core(TM) i9-9900K CPU @ 3.60GHz
Total Number of Cores	8
Memory	32 GB
Graphics Card(s)	Radeon RX 580
Bootloader	Clover - UEFI
AppleHDA	is loaded

Hackintosh Kexts	
AppleALC	1.3.4
FakeSMC	1800
IntelMausiEthernet	2.4.1d1
Lilu	1.3.1
WhateverGreen	1.2.6

All loaded Non-Apple Kexts	
FakeSMC_ACPI Sensors	EFI/CLOVER/kexts/Other
AppleALC	EFI/CLOVER/kexts/Other
FakeSMC_CPUSensors	EFI/CLOVER/kexts/Other
EnergyDriver	/Library/Extensions
FakeSMC	EFI/CLOVER/kexts/Other
FakeSMC_GPUSensors	EFI/CLOVER/kexts/Other
IntelMausiEthernet	EFI/CLOVER/kexts/Other
FakeSMC_LPCSensors	EFI/CLOVER/kexts/Other
Lilu	EFI/CLOVER/kexts/Other
LittleSnitch	/Library/Extensions
FakeSMC_SMM Sensors	EFI/CLOVER/kexts/Other
WhateverGreen	EFI/CLOVER/kexts/Other
ntfs	/System/Library/Extensions