

# hp ZBook G4 opencore

**Beitrag von „gamal“ vom 2. April 2022, 00:08**

HP ZBook G4

CPU: i7-7820HQ

GPU: NVIDIA Quadro M1200 4GB Graphics

Ram: 16GB DDR4

M.2: 512GB

Everything works except the battery signal does not appear in the top bar and the sound is not recognized from the ground up. Attached is the EFI file used

Please help solve these problems or provide me with the correct EFI files

Please accept my salutations

[EFI](#)

---

**Beitrag von „OSX-Einsteiger“ vom 2. April 2022, 11:22**

Should be in the EFI under OC/kext as an example these kextAirportItlwm.kext , IntelBluetoothFirmware.kext & itlwm.kext .

These kext from the EFI delete and then the EFI here around forum upload Thanks 😊

---

**Beitrag von „gamal“ vom 2. April 2022, 22:14**

### Zitat von OSX-Einsteiger

Should be in the EFI under OC/kext as an example these kextAirportItlwm.kext , IntelBluetoothFirmware.kext & itlwm.kext .

These kext from the EFI delete and then the EFI here around forum upload Thanks 😊

I did not understand the point ? I did not understand the point ?

---

### **Beitrag von „OSX-Einsteiger“ vom 2. April 2022, 22:29**

Sorry for my bad English 😊 deepL .

Out of space you should delete this kext , otherwise you can not upload the EFI here. For this forum there is a memory limit

Edit:

Which bootloader do you use Clover or OpenCore